



In series

The model is in series and available for the long term.



Specification

Sensor	
Sensor type	CMOS Color
Shutter	Global Shutter
Sensor characteristic	Linear
Pixel Class	1.6 MP
Resolution	1.58 Mpix
Resolution (h x v)	1456 x 1088 Pixel
Aspect ratio	4:3
ADC	12 bit
Color depth (camera)	12 bit
Optical sensor class	1/2.9"
Optical Size	4.996 mm x 3.747 mm
Optical sensor diagonal	6.25 mm 1/2.9"
Pixel size	3.45 μm
CRA (Chief Ray Angle)	0 °
Manufacturer	Sony
Sensor Model	IMX273LQR-C
Gain (master/RGB)	25.4x/16x
AOI horizontal	same frame rate
AOI vertical	increased frame rate
AOI image width / step width	256 / 2
AOI image height / step width	2 / 2
AOI position grid (horizontal/vertical)	2 / 2
Binning horizontal	-
Binning vertical	-
Binning method	Horizontal: addition / Vertical: addition
Binning factor	-
Decimation (subsampling) horizontal	same frame rate
Decimation (subsampling) vertical	increased frame rate
Decimation (subsampling) method	M/C automatic
Decimation (subsampling) factor	2x2



Model

Frame rate freerun mode	254 fps
Frame rate trigger (continuous)	255 fps
Frame rate trigger (maximum)	264 fps
Exposure time (minimum - maximum)	0.021 ms - 2000 ms
Long exposure (maximum)	30606 ms
Line rate freerun mode (line scan)	6577 1/s
Line rate trigger mode (line scan)	7047 1/s
Lines per frame (line scan)	8000
Power consumption	1.6 W - 3.6 W
Image memory	128 MB

Ambient conditions

For PCB versions, refer to the separate hints in the respective documentation.


Allowed device temperature during operation	0 °C - 55 °C / 32 °F - 131 °F
Allowed device temperature during storage	-20 °C - 60 °C / -4 °F - 140 °F
Humidity (relative, non-condensing)	20 % - 80 %

Connectors

Interface connector	Samtec LSHM 20pol
I/O connector	20-pin header (Samtec LSHM-110-L02.5-L-DV-A-N-K-TR)
Power supply	USB cable

Pin assignment I/O connector

1	Input power supply (VCC), 5 V DC USB
2	Do not connect (for future use)
3	Input power supply (VCC), 5 V DC USB
4	Do not connect (for future use)
5	USB 2 data (-)
6	I2C SDA (signal data) 3.3 V
7	USB 2 data (+)
8	I2C SCL (signal clock) 3.3 V
9	Ground (GND)
10	Trigger input without optocoupler 3.3 V
11	USB 3 TX (-)
12	Flash output without optocoupler 3.3 V 8 mA
13	USB 3 TX (+)
14	General Purpose I/O (GPIO) 1, 3.3 V
15	Ground (GND)
16	General Purpose I/O (GPIO) 2, 3.3 V
17	USB 3 RX (-)
18	Do not connect (for future use)
19	USB 3 RX (+)
20	Output power voltage, 5 V (900 mA – camera current depending on sensor)



Design

Lens Mount	C-Mount
IP code	-
Dimensions H/W/L	84.0 mm x 40.0 mm x 29.7 mm
Mass	45 g
Housing material	-

Features

List of on-camera image pre-processing features.

All features of the table are available via our IDS peak software for image pre-processing on the host computer (sensor model dependent).

Image Acquisition	Freerun	✓
	Software trigger	✓
	Hardware trigger	✓
	Trigger controlled exposure	✓
	Denoiser	✓
	Long exposure	✓
	Line scan	✓
Flashing	Flashing	✓
	PWM flashing	✓
Image Adjustments	Auto exposure	✓
	Auto gain	✓
	Auto whitebalance	✓
	Color correction	✓
	Gamma	✓
	LUT	✓
	Mirror/flip	X/Y
On-board Image Processing	Pixel formats	
	Mono8	
	BayerRG8	
	BayerRG10	
	BayerRG10p	
	BayerRG12	
	BayerRG12p	
	BGR8	
	RGB8	
	BGR10p32	
	RGB10p32	
	Region of interest	✓
	Decimation (FPGA)	✓
	Decimation (Sensor)	2x2
Others	Binning (FPGA)	✓
	Binning (Sensor)	
	Chunks	✓
	Sequencer	✓
	Events	✓
	Firmware update	✓
	1st supported firmware version	2.20.17926